

Алматы (7273)495-231
 Ангарск (3955)60-70-56
 Архангельск (8182)63-90-72
 Астрахань (8512)99-46-04
 Барнаул (3852)73-04-60
 Белгород (4722)40-23-64
 Благовещенск (4162)22-76-07
 Брянск (4832)59-03-52
 Владивосток (423)249-28-31
 Владикавказ (8672)28-90-48
 Владимир (4922) 49-43-18
 Волгоград (844)278-03-48
 Вологда (8172)26-41-59
 Воронеж (473)204-51-73
 Екатеринбург (343)384-55-89

Ижевск (3412)26-03-58
 Иваново (4932)77-34-06
 Иркутск (395)279-98-46
 Казань (843)206-01-48
 Калининград (4012)72-03-81
 Калуга (4842)92-23-67
 Кемерово (3842)65-04-62
 Киров (8332)68-02-04
 Коломна (4966)23-41-49
 Кострома (4942)77-07-48
 Краснодар (861)203-40-90
 Красноярск (391)204-63-61
 Курск (4712)77-13-04
 Курган (3522)50-90-47
 Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
 Москва (495)268-04-70
 Мурманск (8152)59-64-93
 Набережные Челны (8552)20-53-41
 Нижний Новгород (831)429-08-12
 Новокузнецк (3843)20-46-81
 Ноябрьск (3496)41-32-12
 Новосибирск (383)227-86-73
 Ноябрьск (3496)41-32-12
 Омск (3812)21-46-40
 Орел (4862)44-53-42
 Оренбург (3532)37-68-04
 Пенза (8412)22-31-16
 Петрозаводск (8142)55-98-37
 Псков (8112)59-10-37

Пермь (342)205-81-47
 Ростов-на-Дону (863)308-18-15
 Рязань (4912)46-61-64
 Самара (846)206-03-16
 Саранск (8342)22-96-24
 Санкт-Петербург (812)309-46-40
 Саратов (845)249-38-78
 Севастополь (8692)22-31-93
 Симферополь (3652)67-13-56
 Смоленск (4812)29-41-54
 Сочи (862)225-72-31
 Ставрополь (8652)20-65-13
 Сыктывкар (8212)25-95-17
 Сургут (3462)77-98-35
 Тамбов (4752)50-40-97

Тверь (4822)63-31-35
 Тольятти (8482)63-91-07
 Томск (3822)98-41-53
 Тула (4872)33-79-87
 Тюмень (3452)66-21-18
 Улан-Удэ (3012)59-97-51
 Ульяновск (8422)24-23-59
 Уфа (347)229-48-12
 Хабаровск (4212)92-98-04
 Чебоксары (8352)28-53-07
 Челябинск (351)202-03-61
 Череповец (8202)49-02-64
 Чита (3022)38-34-83
 Якутск (4112)23-90-97
 Ярославль (4852)69-52-93

Киргизия (996)312-96-26-47

Россия (495)268-04-70

Казахстан (772)734-952-31

<https://helvi.nt-rt.ru> || hvi@nt-rt.ru

Многофункциональные споттеры SPOTCAR EVO

SPOTCAR EVO 4000



INCLUDED

99920218 · Gun · 2m · 3 pins · 50mm²

99920108 · Ground cable · 50mm²

99920525 · Accessories box



Optional TROLLEY

99900194

SPOCAR EVO 4000	
Input voltage	(1ph) 230V 50/60Hz
Power 50%	2,5 KVA
Secondary	13 KVA
Delayed Fuse	T16 A
No load output voltage	8 V
Amp Out	2850 (2%) A
Amp Out Max	3200 A
Insulation	H
Protection Degree	IP22S
Dimens. (LxWxH)	345x250x280 mm
Box (LxWxH)	400x560x410 mm
Weight box/net	23,8 / 23,3 kg
Code	99500043





EN • Multifunction Spotter ideal for quick works on car body, controller by microprocessor easy and fast setting through synergic programs for welding washers, rivets, wavy wires, heating and squeezing function included. Automatic start contact system or manual. Possibility to set the automatic spot welding time Supplied with gun, hearth cable, Kit accessories included: Hammer, 10 pieces three point washers kit, cylindrical head for three point washers, carbon electrode, squeezing electrode




ACCESSORIES FOR SPOTCAR EVO 4000















99920525 Accessories box



1.	99920126	Extractor hammer with mandrels
2.	99920048	Mandrel for 3 points washers
3.	99920042	Carbon electrode · 10 x 300 · lots of 5 pcs
4.	99920524	Electrode for squeezing · Ø 16 mm
5.	99920127	3 pointed washer · lots of 10 pcs

	99920218	Gun 50 mm² · 2 m · conn. 3 pins
	99920108	Ground cable · 50 mm² · direct
	99920181	Ground cable + fast ground · 50 mm² · direct
	99920122	Fast ground

	99920173	Accessories for pulling waved wires
	99920175	Extractor hammer with mandrels
	99920126	Extractor hammer with mandrels

	99920048	Mandrel for 3 points washers
	99920041	3 pointed washer · lots of 20 pcs
	99920127	3 pointed washer · lots of 10 pcs
	99920042	Carbon electrode · 10 x 300 · lots of 5 pcs
	99920050	Copper chromium electrode · Ø 16 mm
	99920177	Electrode for waved wires · Ø 10 mm
	99920524	Electrode for squeezing · Ø 16 mm
	99920178	M10 pointed mass · lots of 1 pcs
	99920189	M10 pointed mass · lots da 5 pcs
	99920138	M8 pointed mass · lots of 1 pcs
	99920188	M8 pointed mass · lots of 5 pcs
	99920116	Waved copper coated wire · 315 mm · lots of 10 pcs
	99920117	Waved copper coated wire · 315 mm · lots of 50 pcs
	99920113	A · Hook gripping head · 6 hook
	99920114	B · Hook gripping head · 8 hook
	99920115	C · Hook gripping head · 10 hook
	99920187	Kit mandrel for spot welding
	99920186	Mandrel for coal heating/crushing spot welder

SPOTCAR EVO 5000



Optional
TROLLEY

99900194



INCLUDED

99920223 · Gun · 2m · 3 pins · 70mm²

99920216 · Ground cable · 70mm²

99920525 · Accessories box



	SPOTCAR EVO 5000
Input voltage	(1ph) 400V 50/60Hz
Power 50%	6 KVA
Secondary	13 KVA
Delayed Fuse	T20 A
No load output voltage	7,5 V
Amp Out	3600 (2%) A
Amp Out Max	5000 A
Insulation	H
Protection Degree	IP22S
Dimens. (LxWxH)	345x250x280 mm
Box (LxWxH)	400x560x410 mm
Weight box/net	29,6 / 28,6 kg
Code	99500044





EN • Multifunction Spotter ideal for quick works on car body, controller by microprocessor easy and fast setting through synergic programs for welding washers, rivets, wavy wires, heating and squeezing function included. Automatic start contact system or manual. Possibility to set the automatic spot welding time Supplied with gun, hearth cable, Kit accessories included: Hammer, 10 pieces three point washers kit, cylindrical head for three point washers, carbon electrode, squeezing electrode




IT • Spotter multifunzione per le riparazioni di carrozzerie. Controllo a microprocessore con programmi sinergici per la saldatura di rondelle, rivetti, filo ondulato, funzione scaldalamiera e schiacciatura. Partenza del ciclo di saldatura per contatto e manuale. Possibilità di impostare il tempo di puntatura automatico. Fornito con pistola e cavo massa, kit accessori composto da: martello estrattore, 10 rondelle tre punte, testina per rondelle tre punte, elettrodo in carbone, elettrodo per schiacciatura.















ACCESSORIES FOR SPOTCAR EVO 5000



1.	99920126	Extractor hammer with mandrels
2.	99920048	Mandrel for 3 points washers
3.	99920042	Carbon electrode · 10 x 300 · lots of 5 pcs
4.	99920524	Electrode for squeezing · Ø 16 mm
5.	99920127	3 pointed washer · lots of 10 pcs

	99920223	Gun · 70 mm² · 2 m · conn. 3 pins
	99920216	Ground cable · 70 mm² · direct
	99920182	Ground cable + fast ground · 50 mm² · direct · 50 mm²
	99920122	Fast ground

	99920173	Accessories for pulling waded wires
	99920175	Extractor hammer with mandrels
	99920126	Extractor hammer with mandrels

	99920048	Mandrel for 3 points washers
	99920041	3 pointed washer · lots of 20 pcs
	99920127	3 pointed washer · lots of 10 pcs
	99920042	Carbon electrode · 10 x 300 · lots of 5 pcs
	99920050	Copper chromium electrode · Ø 16 mm
	99920177	Electrode for waved wires · Ø 10 mm
	99920524	Electrode for squeezing · Ø 16 mm
	99920178	M10 pointed mass · lots of 1 pcs
	99920189	M10 pointed mass · lots da 5 pcs
	99920138	M8 pointed mass · lots of 1 pcs
	99920188	M8 pointed mass · lots of 5 pcs
	99920116	Waved copper coated wire · 315 mm · lots of 10 pcs
	99920117	Waved copper coated wire · 315 mm · lots of 50 pcs
	99920113	A · Hook gripping head · 6 hook
	99920114	B · Hook gripping head · 8 hook
	99920115	C · Hook gripping head · 10 hook
	99920190	Welding spray resistant fabric up to 1000°C · 92 x 200 cm
	99920090	Electrode Holder mandrel with nut

Алматы (7273)495-231
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922) 49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Ижевск (3412)26-03-58
Иваново (4932)77-34-06
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Копомна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Ноябрьск (3496)41-32-12
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Орск (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Саранск (8342)22-96-24
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сыктывкар (8212)25-95-17
Сургут (3462)77-98-35
Тамбов (4752)50-40-97

Тверь (4822)63-31-35
Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Улан-Удэ (3012)59-97-51
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Киргизия (996)312-96-26-47

Россия (495)268-04-70

Казахстан (772)734-952-31